

W Foldable Wagon

How to fold your wagon

1. Pull on the strap in the center inside the wagon as pictured.



2. Push the wagon handle bars towards each other and then place the wagon cover over the wagon.



W Foldable Wagon

How to unfold your wagon

1. Remove the wagon from its cover then, pull both ends of the wagon apart as pictured.



2. Straighten the wagon out by making sure the handle bars have reached maximum possible distance.

